Catalogue

Features and Specifications.....
Settings.....1
Settings of Muti-languages and Inventory Data Upload.....3
Set Enter.....6
Set Line Skipping.....7
Set Prefixes.....8
Bar Codes for Parameters.....10
Basic Settings of Typical Bar Codes.....13
Warranty.....16
Warranty Card and Configuration List.....17

Respected clients：

Thanks for choosing us. We hope you take your valuable time to read the user manual before using the barcode reader. Hope this will be a good base for a smooth use.
Any enquiries, please contact us. Thanks.

I Product Characteristic:

a.Exquisite and beautiful design, external protected by soft rubber and internal scientific solidification structure, so its drop resistance better than ordinary scanner.

b.The latest technical accomplishment is applied to the engine and decoding function, reading codes better and faster than the similar in the market

c.Easy using, easy setting.

d.Large capacity, 1.5 times higher than ordinary scanner, it guarantees use longer after fully charged.

II Function and Use Description

a.Automatic frequency hopping and strong anti-interference capacity.

b.Under the “Normal Mode”, the transmission distance is 20m-100m where there are obstacles, the transmission distance is over 400m where there are no obstacles. If exceed the transmission distance or the data is loaded failed,3 short prompt sound will be sent out.

c.Each scanner has a unique mechanical ID, it guarantees not disturb each other when many scanners work at the same time.

d.The customized ID enables the user to distinguish the data source easily.

e.The pairing method is very simple, one pairing can be used for a long time and repeated pairing is applicable.

f.The “Checking Mode”is simple and can be used easily, and can storage 5000-10000 barcode messages.

g.Automatic sleeping, the sleeping current is less than 10UA, which largely extends the battery standby time.

h.A special charging circuit guarantees the charging safety.

—: Pairing and ID Setting

Enable Pairing

Enable ID Setting.

About the Pairing: The pairing succeeds when the computer, plugged with the receiver, reads “ Pairing Enabled” within 5 seconds and beeps twice. However, the pairing fails if the computer beeps for three times, which requires you to unplug the receiver and repeat the pairing.

*Set the bar codes for the parameters

0

1

2

3

4

5

6

7

8

9

ID Displayed

ID Hidden

(一) Settings of Sleep Time

Enable the Time Setting

20 seconds

30 seconds

60 seconds

2 minutes

5 minutes

10 minutes

20 minutes

No Sleep

(二) Settings of Work Modes

Regular Mode

Non-interval Mode

Inventory Mode

Upload Data

Totals of Data

Remove Data

二. Upload Speed of Inventory Data

0. 1 second

0.5 second

1 second

三. Muti-languages Settings

English

Italian

German

French

Turkish

Czech

Finnish

Spanish

四. Wireless Settings

Shutdown

Restore of Wireless Programs

五. Decode to Restore the Factory Default

Access Setting

Decode to Restore the Factory Default

Note: All the settings can be decoded to restore their factory defaults by reading Access Setting-->Decode to Restore the Factory Default--> Quit Setting.

Quit Setting

Access Setting

六. Enable and Disable Bar Codes

Enable All the Bar Codes

Disable All the One
-dimensional Bar Codes

Enable All the One
-dimensional Bar Codes

Disable All the Two
-dimensional Bar Codes

Enable All the Two-
dimensional Bar Codes

Quit Setting

Access Setting

七. Set Enter

Do Not Enter

Enable the Suffixes

Enter

Note: 1. You can choose not to press enter by sequentially scanning the bar codes of Access Setting, Do Not Enter, and Quit Setting.

2.You can choose to press enter by sequentially scanning the. bar codes of Access Setting, Enter, and Enable the Suffixes

Quit Setting

Access Setting

八. Set Line Skipping

Enable the Suffixes

Line Skipping

Note: You can add the skipped line by sequentially scanning the bar codes of Access Setting, Enable the Suffixes, and Line Skipping.

Quit Setting

Access Setting

九. Set Prefixes

Disable Prefixes

Enable Prefixes

Set Prefixes

Note: The process of setting the prefixes such as "A" of the bar codes is as follows: Sequentially Read: Access Setting-->Enable Prefixes-->Parameter Bar Code 4--> Parameter Bar Code 1--> Save Setting-->Quit Setting. Please refer to the Table of Parameter Bar Codes and their Corresponding Characters when setting the characters.

Quit Setting

Access Setting

十. Set Suffixes

Disable Suffixes

Enable Suffixes

Set Suffixes

Note: The process of setting the suffixes such as "B" of the bar codes is as follows: Sequentially Read: Access Setting-->Enable Suffixes-->Parameter Bar Code 4 --> Parameter Bar Code 2--> Save Setting-->Quit Setting. Please refer to the Table of Parameter Bar Codes and their Corresponding Characters when setting the characters.

Quit Setting

十一. Parameter Bar Code

0

1

2

3

4

5

6

7

8

9

A

B

C

D

E

F

Save Setting

Cancel the Currently Set Data

Cancel the Currently Set Data String

Cancel the Current Setting

Quit Setting

十二. Table of Parameter Bar Codes and their Corresponding Characters

Parameter Bar Code	Corresponding Character	Parameter Bar Code	Corresponding Character	Parameter Bar Code	Corresponding Character	Parameter Bar Code	Corresponding Character	Parameter CoBar de	Corresponding Character
2 d	-	4 4	D	5 b	[	7 2	r	2 b	+
2 e	·	4 5	E	5 c	\	7 3	s	2 c	,
2 f	/	4 6	F	5 d	]	7 4	t		
3 0	0	4 7	G	5 e	^	7 5	u		
3 1	1	4 8	H	5 f	–	7 6	v		
3 2	2	4 9	I	6 0	'	7 7	w		
3 3	3	4 a	J	6 1	a	7 8	x		
3 4	4	4 b	K	6 2	b	7 9	y		
3 5	5	4 c	L	6 3	c	7 a	z		
3 6	6	4 d	M	6 4	d	7 b	{		
3 7	7	4 e	N	6 5	e	7 c	|		
3 8	8	4 f	O	6 6	f	7 d	}		
3 9	9	5 0	P	6 7	g	7 e	~		
3 a	:	5 1	Q	6 8	h	2 1	!		
3 b	;	5 2	R	6 9	i	2 2	"		
3 c	<	5 3	S	6 a	j	2 3	#		
3 d	=	5 4	T	6 b	k	2 4	$		
3 e	>	5 5	U	6 c	l	2 5	%		
3 f	?	5 6	V	6 d	m	2 6	&		
4 0	@	5 7	W	6 e	n	2 7	`		
4 1	A	5 8	X	6 f	o	2 8	(		
4 2	B	5 9	Y	7 0	p	2 9	)		
4 3	C	5 a	Z	7 1	q	2 a	*		

十三. Basic Settings of Typical Bar Codes

ENA-8 Setting

Do Not Transfers Identifying Character

Read 2-digit Extension Code

Read 5-digit Extension Code

EAN-13 Setting

Do Not Transfer Identifying Characters

Read 2-digit Extension Code

Read 5-digit Extension Code

UPC - E Setting

Do Not Transfer Identifying Characters

Read 2-digit Extension Code

Read 5-digit Extension Code

UPC -A Setting

Do Not Transfer Identifying Characters

Read 2-digit Extension Code

Read 5-digit Extension Code

Code39 Setting

Do Not Transfer the Initial Character and the Terminator

Read Full-ASCII Character

Do Not Read Full -ASCII Character

Codabar Setting

Do Not Transfer the Initial Character and the Terminator

Code 11 Setting

Do Not Transfer Identifying Character

Aztec Setting

Start

About the Warranty

I.Since you buy our product with this card, you can enjoy the service of one year repair and lifelong maintenance for the rubber and plastic parts of the barcode scanner,6 months repair service for the battery and the charger, and 3 months repair service for the data cable. During the repair period, the maintenance of the product is free. Expire the warranty, we will charge the replaced components and maintenance cost.

II. If the product belongs to one of the below situations and verified by manufacturer, the user can't enjoy the free maintenance service:

a. Expire the warranty period;

b. The barcode scanner body is disassembled or the camera of the scanner is damaged;

c. The surface or internal component of the scanner is seriously damaged;

d. The product is damaged due to the wrong installation or operation;

e. The serial number of the scanner is altered or does not confirm to the number written on the card.

f. The scanner is damaged due to an artificial fault. For instance, it is inundate.

g. The scanner is damaged due to natural disasters, e.g. fire disaster, flood and thunder stroke.

h. The working or storage environment of the product, e.g. temperature or humidity, does not conform to the requirements in Operation Manual.

Thank You For Choosing Our Products !

User Information	
Name	
Address	
Zipcode	
Tel	
Email	

Distributor Information	
Name	
Address	
Zipcode	
Operator Signature	
Distributor Seal	

Barcode Reader Warranty Card

Part No.	
Serial No.	
Purchase Date	

Appendix

Accessories Name	Quantity
Scanner	1
U Type Receiver	1
USB Charge Cable	1
Manual	1

Maintenance Record List

Date	Fault Description	Maintenance Record	Operator

Please make sure to read the instructions about maintenance carefully at the back of the card, fill out various data above carefully and the file is valid only if it is signed with the official seal of the authorized dealer.