

简易操作指南
Quick Start Guide


在保修期内出现的非人为损坏造成的产品性能故障可以享受以下服务：
1. 整机质保2年。
2. 保内出现产品质量问题，提供免费维修。

It applies to during the warranty period product performance problems caused by Non-human damage may enjoy the following services:
1. The scanners warranty 2 years.
2. Products quality problems in valid time, provide free maintenance.


将线缆连接到主机和扫面器，待系统识别扫描设备后进行后续的设置。

Connecting the Scanner : Plug cable in scanner and device , and then you can use the scanner.


角度支架朝上安装
Angle stand install upward



水平放置
Place scanner horizontally



角度支架朝下安装
Angle stand install downward



前倾15度放置
Pitch forward 15deg



恢复默认设置
Restore Defaults



只开零售码制
Only Enable Retail Barcode

- ☆ 用于零售扫码应用，有助于优化扫描效率。
开启码制：UPC, EAN, Code128, QR, PDF417.
- ☆ Make for optimize scan performance in most retail barcode scan use case.
Symbology: UPC, EAN, Code128, QR, PDF417.



添加后缀 · Add Suffix

添加后缀 · Add Suffix

扫描模式切换 · Scan Mode Switching

扫描模式切换

Scan Mode Switching

扫描模式组合一 (默认) · Scan Mode Group 1 (Default)

扫描模式组合二 · Scan Mode Group 2

扫描模式组合三 · Scan Mode Group 3



后缀 回车+换行

Add CR + LF Suffix

090300



后缀 换行

Add LF Suffix


090202



按键切换 (默认)

Button Switch (Default)

0E06030



扫描仪顶部按键可以快速切换以下扫描模式，蓝黄色灯指示当前模式。用户可为扫描仪设定两种扫描模式，见“扫描模式组合”配置为“按键切换”时，在黄灯模式下，单击按键切换回蓝灯模式。配置为“自动切换”时，在黄灯模式下，扫码成功或30秒超时后，扫描仪会自动返回蓝灯模式。

普通扫描	支持扫描各种印刷条码，手机屏幕条码，小尺寸条码。
一维码快扫	支持批量快速扫描纸质或手机屏幕一维条码。
关闭扫描	扫描仪不工作。
屏幕扫描	可用于扫描低亮度手机屏幕条码，高反光物体表面的条码，配置方法见“用户手册”。



后缀 回车

Add CR Suffix

090200



后缀 TAB

Add TAB Suffix


090201



自动切换

Auto Switch

0E060330000



Press button to quick switch below scan mode, the top color led indicate current scan mode. User can set 2 scan mode to scanner, see “Scan Mode Group” If setting scan mode “Button Switch”, user can press top button to switch over from yellow scan mode to blue scan mode. If setting scan mode “Auto Switch”, in yellow scan mode, after decoding success or 30 seconds timeout, the scanner will auto switch to blue scan mode.

Normal Scan	Support scanning print barcode, cellphone screen barcode, small size barcode.
1D Fast Scan	Support fast scanning 1D print barcode, 1D cellphone screen barcode continuously.
Disable Scan	Scanner stop working.
Screen Scan	Support scanning low light screen barcode, mirror like surface barcode, see setting in “User Guide”

模式灯


Scan Mode Led



090911

普通扫描 Normal Scan

一维码快扫 1D Fast Scan



090913

关闭扫描 Disable Scan

普通扫描 Normal Scan



090915

关闭扫描 Disable Scan

一维码快扫 1D Fast Scan